		1
ITEM NO.	DESCRIPTION:	QTY:
1	Z34 Drift Upright RHS	1
2	Z34 Drift Upright LHS	1
3	YPB12T 14.2 x 55.5 - LM	2
4	YPB12T 14.2 x 45.5 - LM	2
5	PCYXX10T 12.2 x 100.5 - LM	2
6	THREAD ADAPTER M14x1.5 - 97mm	2
7	ACKERMANN OFFSET WASHER	4
8	ACKERMANN ADJUSTER 3mm SHEET - TOP	2
9	ACKERMANN ADJUSTER 3mm SHEET - BOTTOM	2
10	HEX JAM NUT 5/8-18	2
11	GK ROD END - PCYML10TS	2
12	PCY10TS BOOT	2
13	M14 x 80 Washer	2
14	M14 x 50 HEX	4
15	M14 Washer	8
16	M14 Spring Stop Locknut	2
17	M12 x 95 HEX	2
18	M12 x 55 SHCS	8
19	M12 Washer	8
20	M10 x 43 Shoulder Bolt 10x30	2
21	M10 Washer	2
22	M10 Spring Stop Locknut	2
23	M6 x 12 SHCS	2
24	M6 Washer	2

(24) (20) 9 5 (13) (15) (15) (12) (16) (8) (11)(10) (6) (15)


DIAGRAM A



TABLE (i)

STEP 1. FUCA TO CHASSIS: INSTALL THE FRONT UPPER CONTROL ARM.

SELECT BETWEEN A LOW, OR HIGH CASTER BASED ON YOUR DESIRED ALIGNMENT SPECS.
INSTALL THE FRONT UPPER CONTROL ARM (FUCA) AND EXTEND IT TO THE MAXIMUM LENGTH, AS SHOWN IN DIAGRAMS B AND C.



STEP 2. FLCA TO CHASSIS: INSTALL THE FRONT LOWER CONTROL ARM.

(THE ALIGNMENT SHOULD BE FINE TUNED BY ADJUSTING THE FLCA LATER, SO SIMPLY SET THE ADJUSTMENT TO A BALL PARK VALUE AND INSTALL THE ARM.)



STEP 3. HUB INSTALL: FIT AND TORQUE THE HUB TO THE KNUCKLE (DIAGRAM D).

STEP 4. OUTER TIE ROD INSTALL: INSTALL THE OUTER TIE TOD TO THE KNUCKLE (DIAGRAM E).

