



NOTE

The OEM knuckle has two castings marks that may interfere with the upper camber arms during suspension operation.

This is most commonly seen when running either a low ride height, having soft suspension or when the suspension is compressed and on or near full steering lock.

We do recommend, regardless, grinding the casting marks flush to avoid any possible contact being made.